

Lock Seal Assembly



Part Numbers	Lock Seal Components
93210120	Lock Seal head less seal
93210121	Lock Seal head tapered less seal
93280148	Lock Seal head with aluminum seal (silver)
93280156	Lock Seal head tapered with aluminum seal (silver)
93210140	Stud—regular diameter
93210141	Stud—small diameter
93210142	Stud—regular diameter extra long (1½")
93210130	Replacementseal- aluminum (silver)
93280139	Lock Seal key
93280160	Seal Press

Description

The Lock Seal Assembly is a cost effective locking and sealing device in a single unit. When installed on a wing or wingless style gas cock, or meter connection nut with mating security hardware, the lock seal provides positive protection against unauthorized use of gas. Violation of the replacement seal readily provides evidence of any tampering.

Construction

Both the stud and lock seal head are case hardened steel with plating for corrosion protection. Replacement seals are available in aluminum (silver color) and copper (copper color) for visual identification.

Installation (locked position)

Simply snap the lock seal head onto the stud.

Removal (unlocked position)

Break the replacement seal by opening the tab and peeling away the replacement seal from the lock seal head. Insert the lock seal key into the exposed lock seal head and separate the head from the stud.

Resealing

Crimp the cement seal onto the lock seal head using the seal press and repeat the installation procedure.



Typical Application